




EN



MC62

## USER'S AND INSTALLER'S MANUAL



**motorline®**  
PROFESSIONAL

COMPATIBLE WITH  
MCONNECT LINK

v3.2 REV. 06/2025

HW: MC62\_V.0.3.7 | FW: MC62.v1.r128

|  |     |
|--|-----|
| <b>01. SAFETY INSTRUCTIONS</b>           | 3A  |
| <b>02. CONTROL BOARD</b>                 |     |
| CHARACTERISTICS                          | 5B  |
| RECOMMENDATIONS PRIOR TO PROGRAMMING     | 6A  |
| <b>03. INSTALLATION</b>                  |     |
| INSTALLATION OF MCONNECT LINK (OPTIONAL) | 6B  |
| BASE INSTALLATION PROCESS                | 7A  |
| REMOTE CONTROLS                          | 7B  |
| FUNCTIONS                                | 8A  |
| FUNCTIONS MENU "P"                       | 8B  |
| FUNCTIONS MENU "E"                       | 9A  |
| <b>04. PROGRAMMING "P"</b>               |     |
| P0-COURSE PROGRAMMING                    | 9B  |
| P1-DECELERATION TIME ADJUSTMENT          | 10A |
| P2-FORCE AND SENSITIVITY ADJUSTMENT      | 10B |
| P3-PEDESTRIAN COURSE TIME                | 10B |
| P4-PAUSE TIME AND GATES DELAY            | 11A |
| P5-PHOTOCELLS 1 PROGRAMMING              | 11A |
| P6-PHOTOCELLS 2 PROGRAMMING              | 11B |
| P7-OPERATING LOGIC                       | 11B |
| P8-FLASHING LAMP                         | 12A |
| P9-REMOTE PROGRAMMING                    | 12A |
| <b>05. PROGRAMMING "E"</b>               |     |
| E0-HUMAN PRESENCE                        | 12B |
| E1-SOFT START                            | 13A |
| E2-COURTESY LIGHT TIME                   | 13A |
| E3-FOLLOW ME                             | 13B |
| E4-COURSE TIME ADJUSTMENT                | 13B |
| E5-BRAKE/LOCK/PUSH                       | 14A |
| E6-DECELERATION SPEED                    | 14A |
| E7-MANUEVERS COUNTER                     | 14B |
| E8-RESET - RESET FACTORY VALUES          | 15A |
| E9-RGB OUTPUT                            | 15A |

|  |     |
|--|-----|
| <b>06. DISPLAY</b>                             |     |
| DISPLAY INDICATIONS                            | 15B |
| <b>07. TROUBLESHOOTING</b>                     |     |
| INSTRUCTIONS FOR FINAL CONSUMERS / TECHNICIANS | 16  |
| <b>08. CONNECTIONS SCHEME</b>                  |     |
| CONNECTIONS MAP                                | 17  |
| ACTIVE PHOTOCELL TEST                          | 18  |

### Simplified EU Declaration of Conformity

The undersigned **MOTORLINE ELECTROCELOS, S.A.**, with registered office at Travessa do Sobreiro, n.º 29, 4755-474 Rio Côvo (Santa Eugénia), Barcelos, declares that the present type of radio equipment - **MC62 Control board** - complies with the Directive 2014/53/EU.

The full text of the declaration of conformity is available at the following internet address:

<https://motorline.pt/certification/mc62>



## 01. SAFETY INSTRUCTIONS

|  |   |
|--|---|
|  | This product is certified in accordance with European Community (EC) safety standards.  |
|  | This product complies with Directive 2011/65/EU of the European Parliament and of the Council, of 8 June 2011, on the restriction of the use of certain hazardous substances in electrical and electronic equipment and with Delegated Directive (EU) 2015/863 from Commission.   |
|  | (Applicable in countries with recycling systems). This marking on the product or literature indicates that the product and electronic accessories (eg. Charger, USB cable, electronic material, controls, etc.) should not be disposed of as other household waste at the end of its useful life. To avoid possible harm to the environment or human health resulting from the uncontrolled disposal of waste, separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Home users should contact the dealer where they purchased this product or the National Environment Agency for details on where and how they can take these items for environmentally safe recycling. Business users should contact their vendor and check the terms and conditions of the purchase agreement. This product and its electronic accessories should not be mixed with other commercial waste. |
|  | This marking indicates that batteries should not be discarded like other household waste at the end of their useful life. Batteries must be delivered to selective collection points for recycling.   |
|  | The different types of packaging (cardboard, plastic, etc.) must be subject to selective collection for recycling. Separate packaging and recycle it responsibly.   |
|  | This marking indicates that the product and electronic accessories (eg. charger, USB cable, electronic material, controls, etc.) are susceptible to electric shock by direct or indirect contact with electricity. Be cautious when handling the product and observe all safety procedures in this manual.  |

## 01. SAFETY INSTRUCTIONS

### GENERAL WARNINGS

- This manual contains very important safety and usage information. Read all instructions carefully before beginning the installation/usage procedures and keep this manual in a safe place that it can be consulted whenever necessary.
- This product is intended for use only as described in this manual. Any other enforcement or operation that is not mentioned is expressly prohibited, as it may damage the product and put people at risk causing serious injuries.
- This manual is intended firstly for specialized technicians, and does not invalidate the user's responsibility to read the "User Norms" section in order to ensure the correct functioning of the product.
- The installation and repair of this product may be done by qualified and specialized technicians, to assure every procedure are carried out in accordance with applicable rules and norms. Nonprofessional and inexperienced users are expressly prohibited of taking any action, unless explicitly requested by specialized technicians to do so.
- Installations must be frequently inspected for unbalance and the wear signals of the cables, springs, hinges, wheels, supports and other mechanical assembly parts.
- Do not use the product if it is necessary repair or adjustment is required.
- When performing maintenance, cleaning and replacement of parts, the product must be disconnected from power supply. Also including any operation that requires opening the product cover.
- The use, cleaning and maintenance of this product may be carried out by any persons aged eight years old and over and persons whose physical, sensorial or mental capacities are lower, or by persons without any knowledge of the product, provided that these are supervision and instructions given by persons with experienced in terms of usage of the product in a safe manner and who understands the risks and dangers involved.

- Children shouldn't play with the product or opening devices to avoid the motorized door or gate from being triggered involuntarily.
- If the power cable is damaged, it must be replaced by the manufacturer, after-sales service or similarly qualified personnel to avoid danger.
- The device must be disconnected from the electrical network when removing the battery.
- Ensure that blocking is avoided between the actuated part and its fixed parts due to the opening movement of the actuated part.

### **WARNINGS FOR TECHNICIANS**

- Before beginning the installation procedures, make sure that you have all the devices and materials necessary to complete the installation of the product.
- You should note your Protection Index (IP) and operating temperature to ensure that is suitable for the installation site.
- Provide the manual of the product to the user and let them know how to handle it in an emergency.
- If the automation is installed on a gate with a pedestrian door, a door locking mechanism must be installed while the gate is in motion.
- Do not install the product "upside down" or supported by elements that do not support its weight. If necessary, add brackets at strategic points to ensure the safety of the automation.
- Do not install the product in explosive site.
- Safety devices must protect the possible crushing, cutting, transport and danger areas of the motorized door or gate.
- Verify that the elements to be automated (gates, door, windows, blinds, etc.) are in perfect function, aligned and level. Also verify if the necessary mechanical stops are in the appropriate places.
- The control board must be installed on a safe place of any fluid (rain, moisture, etc.), dust and pests.
- You must route the various electrical cables through protective tubes, to protect them against mechanical exertions, essentially on

the power supply cable. Please note that all the cables must enter the control board from the bottom.

- If the automation is to be installed at a height of more than 2,5m from the ground or other level of access, the minimum safety and health requirements for the use of work equipment workers at the work of Directive 2009/104/CE of European Parliament and of the Council of 16 September 2009.
- Attach the permanent label for the manual release as close as possible to the release mechanism.
- Disconnect means, such as a switch or circuit breaker on the electrical panel, must be provided on the product's fixed power supply leads in accordance with the installation rules.
- If the product to be installed requires power supply of 230Vac or 110Vac, ensure that connection is to an electrical panel with ground connection.
- The product is only powered by low voltage safety with control board (only at 24V motors).
- Parts/products weighing more than 20 kg must be handled with special care due to the risk of injury. It is recommended to use suitable auxiliary systems for moving or lifting heavy objects.
- Pay special attention to the danger of falling objects or uncontrolled movement of doors/gates during the installation or operation of this product.

### **WARNINGS FOR USERS**

- Keep this manual in a safe place to be consulted whenever necessary.
- If the product has contact with fluids without being prepared, it must immediately disconnect from the power supply to avoid short circuits, and consult a specialized technician.
- Ensure that technician has provided you the product manual and informed you how to handle the product in an emergency.
- If the system requires any repair or modification, unlock the automation, turn off the power and do not use it until all safety

conditions have been met.

- In the event of tripping of circuits breakers or fuse failure, locate the malfunction and solve it before resetting the circuit breaker or replacing the fuse. If the malfunction is not repairable by consult this manual, contact a technician.
- Keep the operation area of the motorized gate free while the gate is in motion, and do not create strength to the gate movement.
- Do not perform any operation on mechanical elements or hinges if the product is in motion.

## RESPONSABILITY

- Supplier disclaims any liability if:
  - Product failure or deformation result from improper installation use or maintenance!
  - Safety norms are not followed in the installation, use and maintenance of the product.
  - Instructions in this manual are not followed.
  - Damaged is caused by unauthorized modifications
  - In these cases, the warranty is voided.

## MOTORLINE ELECTROCELOS SA.

Travessa do Sobreiro, nº29  
4755-474 Rio Côvo (Santa Eugénia)  
Barcelos, Portugal

## SYMBOLS LEGEND:



- Important safety notices



- Useful information



- Programming information



- Potentiometer information



- Connectors information



- Buttons information

The MC62 is a control board with built-in radio control system, developed for the automation of 24V swing gates.

|                                   |   |
|-----------------------------------|---|
| • Power Supply                    | 20/24V AC                                     |
| • Flashing light's output         | 24VDC 4W Max.                                 |
| • RGB Flashing light's output     | 24Vdc 100mA Max.                              |
| • Motor's output                  | 24Vdc 2 x 120W Max.                           |
| • Auxiliary accessories output    | 24V DC 8 W Max.                               |
| • Security and BT remote controls | 24V DC  |
| • Working temperature             | -25°C to + 55°C                               |
| • Incorporated Radio Receptor     | 433,92 MHz                                    |
| • OP remote controls              | 12bits or Rolling Code                        |
| • Maximum Memory Capacity         | 100 (full opening) - 100 (pedestrian opening) |
| • Control Board Dimensions        | 150x100 mm                                    |

## CONNECTORS

|      |  |
|------|--|
| VAC  | <b>01</b> • Power Supply Input - 20/24Vac 120W<br><b>02</b> • Power Supply Input - 20/24Vac 120W   |
| BATT | <b>01</b> • 24Vdc Input for Emergency Battery<br><b>02</b> • COM Input (Solar Panel or Emergency Battery)<br><b>03</b> • 24Vdc Input for Solar Panel |
| LAMP | <b>01</b> • Flashing light's Output - 24Vdc 4W<br><b>02</b> • Flashing light's Output - 0V   |
| MOT1 | <b>01</b> • Motor 1 Output - 24Vdc 120W<br><b>02</b> • Motor 1 Output - 24Vdc 120W   |
| MOT2 | <b>01</b> • Motor 2 Output - 24Vdc 120W<br><b>02</b> • Motor 2 Output - 24Vdc 120W   |
| LOCK | <b>01</b> • ElectricLock Output - 12/24Vdc 12W<br><b>02</b> • ElectricLock Output - 0V   |
| V+   | <b>01</b> • Accessories Output - 24Vdc 8W<br><b>02</b> • Accessories Output - 0V   |

## 02. CONTROL BOARD

## CHARACTERISTICS


|      |   |
|------|---|
| Lo   | 01 • NO input for complete maneuver button<br>02 • Common   |
| LS   | 01 • NO input for pedestrian maneuver button<br>02 • Common |
| LE   | 01 • NC input for external photocells<br>02 • Common        |
| LA   | 01 • NC input for internal photocells<br>02 • Common        |
| LC1  | 01 • NC input for anti-crushing photocells<br>02 • Common   |
| LC2  | 01 • NC input for anti-crushing photocells<br>02 • Common   |
| ANT  | 01 • Antenna<br>02 • GND                                    |
| LINK | Type-C input for MCONNECT LINK connection                   |

## 03. INSTALLATION

## INSTALLATION OF MCONNECT LINK (OPTIONAL)



Update the control board firmware if you don't already have the latest version. Use the **MCONNECT LINK** to complete the update quickly and securely.



## 02. CONTROL BOARD

## RECOMMENDATIONS PRIOR TO PROGRAMMING

To improve the knowledge about the operation of the control board, before setting up, pay particular attention to the following instructions.

|      |  |
|------|--|
| LEDs | LS • LED On when pedestrian opening is active.<br>LO • LED On when full opening is active.<br>LE • LED on when the photocell is active or the LE circuit is closed.<br>LA • LED on when the photocell is active or the LA circuit is closed.<br>LC1 • LED on when the circuit LC1 is closed (anti-crushing photocells).<br>LC2 • LED on when the circuit LC2 is closed (anti-crushing photocells).<br>BT • LED ON when the battery turned on backwards.<br>VDD • LED ON when power is supplied to the microcontroller. |
|------|--|



The installation process assumes that the gate already has mechanical or electrical limit switches installed. For more information read the motor's manual.

01 • Connect all accessories according to the connections diagram (page 17).

02 • Connect the control board to a 20V power supply

03 • Check if the gate movement is the same as shown on the display:



If the display does not match the movement of the gate, switch off the control board from power supply and change the wires of Motor1 (0 and 0) and Motor2 (0 and 0).

04 • Make a course programming - menu P0 (page 9A).

05 • If necessary, adjust the deceleration time of the gate at opening and closing - menu P1 (page 10A).

06 • Adjust the gate force and sensitivity - menu P2 (page 10B).

07 • Re-program the course - menu P0 (page 9B).

08 • Enable or disable the use of Photocells in menu P5 and P6 (page 11A and 11B).


09 • Program a remote control (page 7B).

The control board is now fully configured!

Check the pages of the menu programming if you want to configure other features of the Control board.



After completing the entire installation of the electrical panel, it is mandatory to seal with silicone all openings in the box (accesses, cable passages and slots) to prevent the entry of moisture and insects that could compromise the normal functioning of the electrical components.




SU

SP

Programming a remote control for full opening

Programming a remote control for pedestrian opening



## REMOTE CONTROL PROGRAMMING

01 • Press the **cmd** button for 1 sec.

02 • Select the function where you want to program the remote controls (SU and SP) using  $\downarrow \uparrow$ .

03 • Press **cmd** once to confirm the function (SE or SP).

04 • The first free position appears.

05 • Press the remote control button you want to program. The display will blink and move to the next free location.

## DELETE REMOTE CONTROLS

01 • Press the **cmd** button for 1 sec.

02 • Select the function (SU or SP) using  $\downarrow \uparrow$ .

03 • Press **cmd** once to confirm the function (SU or SP).

04 • Use  $\downarrow \uparrow$  to select the remote control location you want to delete.

05 • Press **cmd** for 3sec. and the position is empty. The display will flash and the position will be available.

## DELETE ALL THE REMOTE CONTROLS

01 • Press the **cmd** button for 5 sec.

02 • The display will show **dl**, confirming that all remote controls have been deleted.



- Whenever you store or delete a remote control, the display will flash and show the next position. You can add or delete remote controls without go back to point 01.
- If you do not press any button for 20 seconds the control board will return to standby.




We can only go into programming with the gate electrically stumbled.

The functions of the control board are divided into 2 areas:


- Main Menus "P"
- Extra Menus "E"

P MENU



- To access the P menu press the MENU button for 2 sec.
- Use ↓↑ to navigate through the menus.

E MENU



- To access the E menu press the MENU button for 10 sec.
- Use ↓↑ to navigate through the menus.

- Press MENU when you want to confirm access to a menu.
- Press ↓↑ simultaneously to exit programming.

| MENU | FUNCTION                         | MIN. | MAX. | STATE  | FACTORY VALUE | PAGE. |
|------|----------------------------------|------|------|--|---------------|-------|
|      |                                  |      |      | dR Manual Programming  | -             |       |
|      |                                  |      |      | dR 1 motor<br>dR 2 motors  |               |       |
| P0   | Course Programming               | -    | -    | 50 00 Disable Solar Kit Apolo<br>01 Activate Solar Kit Apolo   | 00            | 9B    |
|      |                                  |      |      | 50 00 Disable Chainlift<br>cH 01 Activate Chainlift (sensitivity 9   strength 5)   | 00            |       |
| P8   | Deceleration time adjustment     | 0s   | 25s  | dR Opening deceleration<br>dR Closing deceleration<br>bR Opening deceleration<br>bR Closing deceleration   | 0 / Active    | 3s    |
|      |                                  |      |      | bR   | Leaf 2        | 10A   |
| P2   | Force and sensitivity adjustment | 0    | 9    | fD Force adjustment<br>fS Sensitivity adjustment<br>fR Slowdown sensitivity adjustment   | 05            | 10B   |
| P3   | Pedestrian Course time           | 0s   | 99s  | Time setting in pedestrian mode  | 10s           | 10B   |
| P4   | Pause time and Gates delay       | 0s   | 99s  | RP Full pause time adjustment<br>RP Pedestrian pause time adjustment   | 0s            | 11A   |
|      |                                  | 0s   | 25s  | Rc Gate delay in closing<br>Ro Gate delay in opening   | 2s            |       |
|      |                                  |      |      | LE 00 Disables photocells<br>01 Activates photocells   | 00            |       |
|      |                                  |      |      | HC 00 Photocells in opening<br>01 Photocells in closing  | 01            |       |
| P5   | Photocells 1 programming         | -    | -    | 00 Invert<br>01 Stop<br>02 Invert 2 sec. and Stop  | 00            | 11A   |
|      |                                  |      |      | LC 00 Disables anti-crushing photocells LC1<br>01 Activates anti-crushing photocells LC1   | 00            |       |
|      |                                  |      |      | Sc 00 Deactivates photocell test<br>01 Activates photocell test  | 00            |       |
|      |                                  |      |      | LR 00 Disables photocells<br>01 Activates photocells   | 00            |       |
|      |                                  |      |      | HC 00 In opening<br>01 In closing<br>02 In opening and closing   | 00            |       |
| P6   | Photocells 2 programming         | -    | -    | 00 Invert<br>01 Stop<br>02 Invert 2 sec. and Stop<br>03 Invert at close/stop 2sec at opening<br>04 Stops when closing and reverses when the obstacle comes out. / Stops at the opening and continues when the obstacle comes out | 01            | 11B   |
|      |                                  |      |      | LC 00 Disables anti-crushing photocells LC2<br>01 Activates anti-crushing photocells LC2   | 00            |       |
|      |                                  |      |      | Sc 00 Deactivates photocell test<br>01 Activates photocell test  | 00            |       |
| P8   | Operating logic                  | -    | -    | 00 Automatic mode functioning<br>01 Step by step mode functioning<br>02 Condominium mode functioning   | 01            | 11B   |
| P8   | Flashing lamp                    | -    | -    | 00 Flashing (opening and closing)<br>01 Step by step mode<br>02 Courtesy light   | 00            | 12A   |
| P9   | Remote programming               | -    | -    | 00 Distance PGM OFF<br>01 Distance PGM ON  | 00            | 12B   |

### 03. INSTALLATION

### FUNCTIONS MENU "E"

| MENU | FUNCTION                                | MIN. | MAX. | STATE  | FACTORY VALUE | PAGE |
|------|---|------|------|--|---------------|------|
| E0   | Human Presence                          | -    | -    | HP 00 Desactivates human presence<br>01 Activates human presence                       | 00            | 12A  |
|      |   |      |      | PU 00 Disables push buttons mode<br>01 Activates push buttons mode                     | 00            |      |
|      |   |      |      | US 00 Disables input for emergency stop devices  | 00            |      |
|      |   |      |      | ES 01 Enables input for emergency stop (NC) devices                                    | 00            |      |
| E8   | Soft start                              | -    | -    | 00 Deactivates Soft start<br>01 Activates Soft start                                   | 00            | 12B  |
| E2   | Courtesy light time / Pre-Flashing lamp | 0    | 99   | LB Courtesy light time adjustment  | 00            | 12B  |
|      |   |      |      | PP Adjustment of Pre-Flashing lamp time  | 00            |      |
| E3   | Follow me                               | -    | -    | 00 Desactivates follow me  | 00            | 13A  |
|      |   |      |      | 01 Activates Follow me (fully open)  |               |      |
|      |   |      |      | 02 Activates Follow me (in opening or fully open position)                             |               |      |
| E4   | Course time adjustment                  | 1m   | 4m   | 00 Opening course time (minutes)   | 00            | 13A  |
|      |   | 0s   | 59s  | 05 Opening course time (seconds)   | 10s           |      |
|      |   | 1m   | 4m   | 00 Closing course time (minutes)   | 00            |      |
|      |   | 0s   | 59s  | 05 Closing course time (seconds)   | 10s           |      |
|      |   | 1m   | 4m   | 00 Opening course time (minutes)   | 00            |      |
|      |   | 0s   | 59s  | 05 Opening course time (seconds)   | 10s           |      |
|      |   | 1m   | 4m   | 00 Closing course time (minutes)   | 00            |      |
|      |   | 0s   | 59s  | 05 Closing course time (seconds)   | 10s           |      |
| E5   | Brake/Lock/Strokes                      | -    | -    | EB 00 Disables electronic brake<br>01 Active electronic brake                          | 00            | 13B  |
|      |   |      |      | EL 00 Activates electric lock on opening<br>01 Activates electric lock whenever moving | 00            |      |
|      |   |      |      | PO 00 Disables opening push<br>01 Active opening push                                  | 00            |      |
|      |   |      |      | PC 00 Disables closing push<br>01 Active closing push                                  | 00            |      |
|      |   |      |      | PR 00 Motor lock on closing disabled<br>01 Motor lock on closing activated             | 00            |      |
|      |   |      |      | SD Deceleration Speed adjustment   | 05            |      |
| E6   | Deceleration Speed                      | 0    | 9    | SD Deceleration Speed adjustment   | 05            | 13B  |
| E8   | Manuevers counter                       | -    | -    | Shows the number of manuevers  | -             | 14A  |
| E8   | Reset - Restore factory settings        | -    | -    | 00 Deactivated<br>01 Reset activated   | 00            | 14B  |
| E9   | RGB Output                              | -    | -    | 00 Continued output<br>01 Intermittent output  | 00            | 14B  |

### 04. PROGRAMMING "P"

### P0 COURSE PROGRAMMING

| AA   | AB   | SO   |  |  |
|--|--|--|--|--|
| <b>Course Manual Programming</b>   | <b>Number of Motors</b>  | <b>Solar kit</b>   |  |  |
| This menu allows you to manually set the course of the leaf/leaves.  | Allows you to define the number of motors connected to the control board | This menu allows activating the solar Kit Apolo mode and its connection with the control board. The RGB Y output changes the operating mode so that it is activated only when the gate is closed, telling the Kit to turn off the power supply. With this menu active, the control board will recognize that it is closed and will open at its normal speed, when given the order. |  |  |
| Default value (NA)   | Default value (02)   | Default value (00)   |  |  |
| DIRECTION OF DISPLAY ROTATION  | COURSE PROGRAMMING OF TWO MOTORS   |  |  |  |
| 00   | Normal rotation - leaf 1 starts opening (normal speed)                   | Slow rotation - leaf 1 goes into opening slowdown (slowdown speed)   |  |  |
| 01   | Normal rotation - leaf 1 stops and leaf 2 starts opening (normal speed)  | Slow rotation - leaf 2 goes into opening slowdown (slowdown speed)   |  |  |
| 02   | Normal rotation - leaf 2 stops and starts closing (normal speed)         | Slow rotation - leaf 2 goes into closing speed (slowdown speed)  |  |  |
| 03   | Normal rotation - leaf 2 stops and leaf 1 starts opening (normal speed)  | Slow rotation - leaf 1 goes into closing slowdown (slowdown speed)   |  |  |
| COURSE PROGRAMMING OF ONE MOTOR (PEDESTRIAN)   |  |  |  |  |
| 00   | Normal rotation - leaf starts opening (normal speed)                     | Slow rotation - the leaf goes into opening slowdown (slowdown speed)   |  |  |
| 01   | Normal rotation - the leaf stops and starts closing (normal speed)       | Slow rotation - the leaf goes into closing slowdown (slowdown speed)   |  |  |
| <b>Manual programming:</b>   |  |  |  |  |
| 01 • Press MENU for 2 sec. until P0 appears.   |  |  |  |  |
| 02 • Press MENU once until AA appears.   |  |  |  |  |
| 03 • Press MENU (or remote control) to start programming the opening time.   |  |  |  |  |
| 2 MOTORS (AA = 02)   | 1 MOTOR (PEDESTRIAN) (AA = 01)   |  |  |  |
| 04 • Press MENU to start slowdown.   | 04 • Press MENU to start the opening slowdown of the leaf.               |  |  |  |
| 05 • Press MENU to stop leaf 1 (leaf 2 starts opening automatically).  | 05 • Press MENU to stop the leaf and start programming the closing time. |  |  |  |
| 06 • Press MENU to start slowdown.   | 06 • Press MENU to start the closing slowdown of the leaf.               |  |  |  |
| 07 • Press MENU to finish opening and start closing leaf 2.  | 07 • Press MENU once to display AB, leaf 1 stops.                        |  |  |  |
| 08 • Press MENU to start slowdown.   | 08 • Use UP and DW to display P0 to exit programming mode.               |  |  |  |
| 09 • Press MENU to stop leaf 2 (leaf 1 starts closing automatically).  | 09 • Use UP and DW to stay in Standby.                                   |  |  |  |
| 10 • Press MENU to start slowdown.   |  |  |  |  |
| 11 • Press MENU to finish closing leaf 1.  |  |  |  |  |
| Display will show AB signaling that leaves are closed.   |  |  |  |  |
|  You can use the remote instead of the MENU button.<br>Whenever a leaf touches a stop, wait 1 second before clicking on the MENU. |  |  |  |  |

## 04. PROGRAMMING "P"

### P0 COURSE PROGRAMMING

#### P0-*n*0 - Number of motors:

- 01 • Press MENU for 2 sec. until *P0* appears.
- 02 • Press MENU once until *n*0 appears.
- 03 • Use UP until *n*0 appears.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

#### P0-*s*0 - Solar kit:

- 01 • Press MENU for 2 sec. until *P0* appears.
- 02 • Press MENU once until *n*0 appears.
- 03 • Use UP until *s*0 appears.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to store the new value.

#### P0-*c*0 - Chainlift:

- 01 • Press MENU for 2 sec. until *P0* appears.
- 02 • Press MENU once until *n*0 appears.
- 03 • Use UP until *c*0 appears.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.



When active(1) the obstacle detection sensitivity is automatically set to 9 and the force to 5

## 04. PROGRAMMING "P"

### P1 DECELERATION TIME ADJUSTMENT

This menu allows to set the deceleration time of each leaf at opening and closing.

**P2****P2**

#### Slowing down on opening leaf 1

It allows to define the time that the gate will act with slowdown in the opening.

#### Slowing down on closing leaf 1

It allows to define the time that the gate will act with slowdown in the closing.

**P2****P2**

#### Slowing down on opening leaf 2

It allows to define the time that the gate will act with slowdown in the opening.

#### Slowing down on closing leaf 2

It allows to define the time that the gate will act with slowdown in the closing.

min. 00s 25s max. Default value (03)

- 01 • Press MENU for 2 sec. until it appears *P0*.

- 02 • Use UP until appears *P1*.

- 03 • Press Menu will appear *P2*. Use UP or DW to navigate the parameters.

- 04 • Press MENU to edit the chosen parameter value.

- 05 • The factory set time appears. Use UP and DW to change the value.

- 06 • Press MENU to save the new value.

- 07 • Press MENU again.

- 08 • Use UP and DW to display *P2* to exit programming mode.

- 09 • Use UP and DW to stay in Standby.

## 04. PROGRAMMING "P"

### P2 FORCE AND SENSITIVITY ADJUSTMENT



A very low value in this parameter may cause the motor to not have enough torque to move the gate and the effort error occurs (*o1* or *o2*)

**P0****P5****P8**

#### Force adjustment

Allows you to set the force that is injected into the motor when it moves at normal speed.

min. 1 9 max.  
Default value (05)

#### Sensitivity adjustment

Allows to adjust the sensitivity of the motor in the presence of obstacles. The higher the sensitivity, the less effort it will take to detect any obstacle and reverse direction.

min. 1 9 max.  
Default value (05)

#### Slowdown sensitivity adjustment

Allows to adjust the sensitivity of the motor in the presence of obstacles. The higher the sensitivity, the less effort it will take to detect any obstacle and reverse direction.

min. 1 9 max.  
Default value (05)

- 01 • Press MENU for 2 sec. until it appears *P0*.

- 02 • Use UP until appears *P2*.

- 03 • Press Menu will appear *P0*. Use UP or DW to navigate the parameters.

- 04 • Press MENU to edit the chosen parameter value.

- 05 • The factory set time appears. Use UP and DW to change the value.

- 06 • Press MENU to save the new value.

## 04. PROGRAMMING "P"

### P3 PEDESTRIAN COURSE TIME

The pedestrian mode allows the gate to be opened for the passage of people, without it needing to open in its entirety.

In this function you can schedule the time you want the gate to open.



For pedestrian mode to work, it is necessary that the minimum work is 1 second, and 0 disables the pedestrian.

min. 0s 99s max.  
Default value (10 secondes)

- 01 • Press MENU for 2 sec. until it appears *P0*.

- 02 • Use UP until appears *P3*.

- 03 • Press MENU. The factory set time appears.

- 04 • Use UP and DW to change the value.

- 05 • Press MENU to save the new value.

## 04. PROGRAMMING "P"

### P4 PAUSE TIME AND GATES DELAY

| RF   | RP   | Rd  | RA  |
|--|--|---|---|
| <b>Closing time adjustment</b><br>Allows adjustment of the pause time for automatic closing. | <b>Pedestrian closing pause time adjustment</b><br>Allows you to set the pause time at the pedestrian opening. | <b>Gate delay in closing</b><br>Allows you to set the delay time for closing leaf 1 relative to leaf 2. | <b>Gate delay in opening</b><br>Allows you to set the delay time for opening leaf 1 relative to leaf 2. |



When the values are at zero, there is no automatic closing.

- 01 • Press MENU for 2 sec. until it appears **P0**.
- 02 • Use UP until appears **P4**.
- 03 • Press Menu will appear **RF**. Use UP or DW to navigate the parameters.
- 04 • Press MENU to edit the chosen parameter value.
- 05 • The factory set time appears. Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

## 04. PROGRAMMING "P"

### P5 PHOTOCELLS 1 PROGRAMMING

|   |   |                    |
|---|---|--------------------|
| Allows to program LE security behavior (photocell 2). |   |                    |
| <b>LE</b>   | <b>00 (disables photocells)   01 (activates photocells)</b><br>Enable or disable security entry.  | Default value (00) |
| <b>HC</b>   | <b>00 (opening photocells)   01 (closing photocells)</b><br>This menu can only be changed when the LE menu is active. Allows you to define whether this security will act when opening or closing the gate.   | Default value (01) |
| <b>HL</b>   | <b>00 (the gate is reversed)</b><br><b>01 (gate stops and resumes 5 sec after security is disabled)</b><br><b>02 (gate reverses for 2 sec. and stop)</b><br>Allows you to set the behavior that the gate will have when this security is activated. | Default value (00) |
| <b>LC</b>   | <b>00 (disables photocells)   01 (activates photocells)</b><br>Allows you to activate or deactivate the LC1 input (anti-crushing photocell 1).  | Default value (00) |
| <b>SC</b>   | <b>00 (Deactivates photocell test)   01 (Activates photocell tests)</b><br>Allows you to activate or deactivate the photocell test.   | Default value (00) |

- 01 • Press MENU for 2 sec. until it appears **P0**.
- 02 • Use UP until appears **P5**.
- 03 • Press Menu will appear **LE**. Use UP or DW to navigate the parameters.
- 04 • Press MENU to edit the chosen parameter value.
- 05 • The factory set time appears. Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

## 04. PROGRAMMING "P"

### P6 PHOTOCELLS 2 PROGRAMMING

|   |   |
|---|---|
| Allows to program LA security behavior (photocell 2). |   |
| <b>LA</b>   | <b>00 (disables photocells)   01 (activates photocells)</b><br>Enable or disable security entry.  |
| <b>HC</b>   | <b>00 (opening photocells)   01 (closing photocells)   02 (In opening - Stops when the photocells are interrupted and resumes opening when they are released; In closing: Stops and reopens as soon as the photocells are released)</b><br>This menu can only be changed when the LA menu is active. Allows you to define whether this security will act on the opening or closing of the gate. |
| <b>HL</b>   | <b>00 (the gate is reversed)</b><br><b>01 (gate stops and resumes 5 sec after security is disabled)</b><br><b>02 (gate reverses for 2 sec. and stop)</b><br>Allows to set the behavior that the gate will have when this security is activated.   |
| <b>LC</b>   | <b>00 (desativa fotocélulas)   01 (ativa fotocélulas)</b><br>Permite ativar ou desativar a entrada LC2 (fotocélula anti-esmagamento 2)  |
| <b>SC</b>   | <b>00 (Deactivates photocell test)   01 (Activates photocell tests)</b><br>Allows you to activate or deactivate the photocell test.   |

\*Note: If you activate parameter **02** in **P6** → **HC**, the **P6** → **HL** menu no longer functions.

- 01 • Press MENU for 2 sec. until it appears **P0**.

- 02 • Use UP until appears **P6**.

- 03 • Press MENU will appear **LA**. Use UP or DW to navigate the parameters.

- 04 • Press MENU to edit the chosen parameter value.

- 05 • The factory set time appears. Use UP and DW to change the value.

- 06 • Press MENU to save the new value.

## 04. PROGRAMMING "P"

### P7 OPERATING LOGIC

This menu allows to set the operating logic of the automation

| 00  | 01   | 02   |
|---|--|--|
| <b>Automatic Mode</b><br>Whenever there is an order the movement is reversed. | <b>Step by step mode</b><br>1st impulse - OPEN<br>2nd impulse - STOP<br>3rd impulse - CLOSE<br>4th impulse - STOP<br>If it is fully open and timed, it closes. | <b>Condominium Mode</b><br>Does not respond to orders during opening and pause time. |

Default value (01)

- 01 • Press MENU for 2 sec. until it appears **P0**.
- 02 • Use UP until appears **P7**.
- 03 • Press Menu will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

This menu allows to set the operation mode of the flashing lamp (LAMP).

| 00   | 01  | 02   |
|--|---|--|
| <b>Intermittent</b><br>The firefly flashes when opening and closing and stays on during the pause time | It remains on when opening and closing and off when paused. | It remains on during the opening and closing movements and off during the pause time and the light will remain on for the time set in menu E2. |

Default value (00)

- 01 • Press MENU for 2 sec. until it appears **P0**.
- 02 • Use UP until appears **P8**.
- 03 • Press Menu will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

| 00               | 01              |
|------------------|-----------------|
| Distance PGM OFF | Distance PGM ON |

This menu allows to enable or disable the programming of new remote controls without directly accessing the control board, using a previously stored remote controls (memorize remote controls page 7B).

Default value (00)

- 01 • Press MENU for 2 sec. until it appears **P0**.
- 02 • Use UP until appears **P9**.
- 03 • Press Menu will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

#### Remote Programming Operation (PGM ON):



- Press the buttons indicated in the image simultaneously for 10 seconds and the flashing lamp will flash (the 1st free position appears in the display).
- Each time you store 1 remote control, the control board will exit remote programming. If you want to memorize more remote controls, you will always have to repeat the process of pressing the remote control buttons simultaneously for 10 seconds for each new remote control.

| HP  | PL  | BS   |    |    |          |              |              |           |                      |                 |   |
|---|---|--|----|----|----------|--------------|--------------|-----------|----------------------|-----------------|---|
| <b>00 (disables human presence)</b><br>Whenever an order is sent to the LO input and the motor performs a complete maneuver.  | <b>00 (disables pushbutton mode)</b><br><b>01 (active pushbutton mode)</b>  | Allows you to define how the LS input works. |    |    |          |              |              |           |                      |                 |   |
| <b>Human presence</b><br><b>01 (active human presence)</b><br>The motor only works if you keep the LS button pressed.<br><br>⚠ With the human presence active the RF remote controls do not work. | <table border="1" style="width: 100%;"> <thead> <tr> <th></th> <th>LS</th> <th>LO</th> </tr> </thead> <tbody> <tr> <td>01<br/>ON</td> <td>Full closing</td> <td>Full opening</td> </tr> <tr> <td>00<br/>OFF</td> <td>Pedestrian maneuvers</td> <td>Total maneuvers</td> </tr> </tbody> </table> |  | LS | LO | 01<br>ON | Full closing | Full opening | 00<br>OFF | Pedestrian maneuvers | Total maneuvers | <b>00 (disables input to emergency stop device)</b><br><br><b>01 (input for emergency stop devices)</b><br><br><br><b>If you have the LS submenu in 01 (active) and the PL submenu in 01 (active), the error appears BL.</b> |
|   | LS  | LO   |    |    |          |              |              |           |                      |                 |   |
| 01<br>ON  | Full closing  | Full opening                                 |    |    |          |              |              |           |                      |                 |   |
| 00<br>OFF   | Pedestrian maneuvers  | Total maneuvers                              |    |    |          |              |              |           |                      |                 |   |

Default value (00)

- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Press MENU until it appears **HP**. Use UP or DW to navigate the parameters.
- 03 • Press MENU to edit the chosen parameter value.
- 04 • The factory set time appears. Use UP and DW to change the value.
- 05 • Press MENU to save the new value.

00 function disabled  
01 function activated

This menu allows activate/disable soft start.

With the soft start function activated, at each start of movement, the control board will control the start of the motor, gradually increasing in the first second of operation.

Default value (00)

- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Use UP until appear **E0**.
- 03 • Press Menu will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

**E7**

Allows to adjust the courtesy light time. The courtesy light is activated for the set time when the gate is in the closed, open and standing position.

The E2 menu will only be available in the case if the courtesy light function is activated in the P8 menu option 2 (see page 12A)

Default value (00)

**P8**

This menu allows you to define the time (from 1 to 99 seconds) that the flashing lamp remains active before the start of each maneuver.

- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Use UP until appears.
- 03 • Press Menu will appear.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

00 function disabled  
01 function activated after opening  
02 function activated on opening

Allows you to activate the Follow me option. With this option activated, the control board, when in the open position or in opening, gives a closing order of 5 sec. after the safety device detects the passage of an object / user.

Default value (00)

- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Use UP until appears **E3**.
- 03 • Press MENU. The factory set time appears.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

It allows to adjust the working time for the opening and closing courses of the two leafs.

Leaf 1

| <b>00</b>                        | <b>05</b>                        | <b>00</b>                        | <b>05</b>                        |
|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Opening course time<br>(minutes) | Opening course time<br>(seconds) | Closing course time<br>(minutes) | Closing course time<br>(seconds) |
| Default value (00)               | Default value (10)               | Default value (00)               | Default value (10)               |

Leaf 2

| <b>00</b>                        | <b>05</b>                        | <b>00</b>                        | <b>05</b>                        |
|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Opening course time<br>(minutes) | Opening course time<br>(seconds) | Closing course time<br>(minutes) | Closing course time<br>(seconds) |
| Default value (00)               | Default value (10)               | Default value (00)               | Default value (10)               |

- 01 • Press MENU for 10 sec. until it appears **E0**.

- 02 • Use UP until appears **E4**.

03 • Press MENU will appear **00**. Use UP or DW to navigate the parameters.

04 • Press MENU to edit the chosen parameter value.

05 • The factory set time appears. Use UP and DW to change the value.

06 • Press MENU to save the new value.


| Allows to program gate behavior   |  |                    |
|---|--|--------------------|
| <b>E8</b>   | <b>00 (disables electronic brake)   01 (activates electronic brake)</b><br>Allows you to activate the electronic brake.  | Default value (00) |
| <b>E8</b>   | <b>00 (active lock on opening 2 sec.)   01 (activates lock whenever in motion)</b><br>Allows you to select the lock's operating mode.<br>The default value is 0 (2 second pulse on opening).<br><b>Note: If you select option 2, you must take into account the maximum current value provided by the control board.</b> | Default value (00) |
| <b>P8</b>   | <b>00 (disable opening push)   01 (active opening push)</b><br>Allows you to activate the opening stroke (ram).  | Default value (00) |
| <b>P8</b>   | <b>00 (disables closing push)   01 (active closing push)</b><br>Allows you to activate the closing push.   | Default value (00) |
| <b>Pr</b>   | <b>00 (deshabilita el bloqueo del motor al cierre)   01 (activa el bloqueo del motor al cerrar)</b><br>Permite activar el bloqueo de los motores en posición cerrada.<br>Sirve principalmente para motores hidráulicos.  | Default value (00) |
| <p><b>01</b> • Press MENU for 10 sec. until it appears <b>E0</b>.</p> <p><b>02</b> • Use UP until appears <b>E5</b>.</p> <p><b>03</b> • Press MENU will appear <b>E8</b>. Use UP or DW to navigate the parameters.</p> <p><b>04</b> • Press MENU to edit the chosen parameter value.</p> <p><b>05</b> • The factory set time appears. Use UP and DW to change the value.</p> <p><b>06</b> • Press MENU to save the new value.</p> |  |                    |

|  |   |        |
|--|---|--------|
| This menu allows you to adjust the deceleration speed.<br>The higher the level, the faster the deceleration. |   |        |
| min.   | 0 | 9 max. |
| Default value (05)   |   |        |
| <b>01</b> • Press MENU for 10 sec. until it appears <b>E0</b> .  |   |        |
| <b>02</b> • Use UP until appears <b>E6</b> .   |   |        |
| <b>03</b> • Press MENU will appear <b>5d</b> .   |   |        |
| <b>04</b> • Press MENU to edit the value.  |   |        |
| <b>05</b> • Use UP and DW to change the value.   |   |        |
| <b>06</b> • Press MENU to save the new value.  |   |        |


This menu allows you to view the number of maneuvers were performed by the control board.  
(complete maneuver means opening and closing).

⚠ **Resetting the control board does not clear the maneuver count.**


**Example:** 13456 maneuvers  
01- Hundred thousand / 34- Thousands / 56- Dozens




**01** • Press MENU for 10 seconds.




**02** • E0 appears.  
Press UP until appears E7.



**03** • Press MENU.



**04** • The maneuvers count is displayed in the following order (example: 130 371)



**05** • E8 appears.



## 05. PROGRAMMING "E"

### E8 RESET - RESET FACTORY VALUES

When resetting, all factory values will be reset.

The memorized remote controls and the maneuver counter will always have the memorized data.

- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Use UP until appears **E8**.
- 03 • Press MENU will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.

## 05. PROGRAMMING "E"

### E9 RGB OUTPUT

**00**

Continuous light

**08**

Flashing light

Default value (00)


- 01 • Press MENU for 10 sec. until it appears **E0**.
- 02 • Use UP until appears **E9**.
- 03 • Press MENU will appear **00**.
- 04 • Press MENU to edit the value.
- 05 • Use UP and DW to change the value.
- 06 • Press MENU to save the new value.


## 06. DISPLAY

### DISPLAY INDICATIONS

| MENU            | DESCRIPTION  |
|-----------------|--|
| <b>88</b>       | In the stopped position, fully open  |
| <b>89</b>       | In the stopped position, intermediate position   |
| <b>8A</b>       | In the stopped position, fully closed  |
| <b>8B</b>       | Full opening button pressed  |
| <b>8S</b>       | Pedestrian opening button pressed  |
| <b>08</b>       | Control board performs the opening course  |
| <b>0A</b>       | Control board performs the closing course  |
| <b>E0</b>       | End of opening course time   |
| <b>E1</b>       | End of opening course time   |
| <b>00</b>       | Full memory  |
| <b>8B</b>       | All remote controls erased   |
| <b>00 08 02</b> | Remote control triggered from the indicated position                                     |
| <b>8E</b>       | Obstructed photocell   |
| <b>8A</b>       | Obstructed photocell   |
| <b>8B</b>       | In pause time  |
| <b>8B</b>       | In time of pedestrian pause  |
| <b>8B</b>       | Motor 1 overcurrent detection  |
| <b>82</b>       | Motor 2 overcurrent detection  |
| <b>8B</b>       | Emergency stop circuit opened.<br>Check that the security button is correctly connected. |
| <b>PA</b>       | Control in Pre-Flashing lamp   |
| <b>58</b>       | Photocell test failed  |

| Anomaly                               | Procedure  | Behavior                                    | Procedure II  | Discovering the origin of the problem  |
|---------------------------------------|--|---|---|--|
| • Motor doesn't work.                 | • Make sure you have power supply 230/110V connected to control board and if it is working properly.   | • Still not working.                        | • Consult a qualified technician MOTORLINE.   | 1 • Open control board and check if it has 230/110V power supply;<br>2 • Check input fuses;<br>3 • Disconnect motors from control board and test them by connecting directly to a 12/24V battery in order to find out if they have problems.<br>4 • If the motors work, the problem is on the control board.<br>Pull it out and send it to our MOTORLINE technical services for diagnosis;<br>5 • If the motors don't work, remove them from installation site and send to our technical services for diagnosis.   |
| • Motor doesn't move but makes noise. | • Unlock motor and move the gate by hand to check for mechanical problems on the movement.   | • Encountered problems?                     | • Consult a qualified gates technician.   | 1 • Check all motion axis and associated motion systems related with the gate and automation (rails, pulleys, bolts, hinges, etc) to find out what is the problem.   |
|                                       | • The gate moves easily?   | • Consult a qualified MOTORLINE technician. | 1 • If the motors work, the problem is on the control board. Pull it out and send it to our MOTORLINE technical services for diagnosis;<br>2 • If the motors don't work, remove them from installation site and send to our MOTORLINE technical services for diagnosis. |  |
| • Motors open but doesn't close.      | • Unlock motor and move the gate by hand to closed position. Block the motor again and turn off power supply for 5 seconds. Reconnect it and send order to open gate using remote control. | • Gate opened but didn't close again.       |   | <p>All control boards have LEDs that easily allow to conclude which devices are with anomalies. All safety devices LEDs (DS) in normal situations remain On. All "START" LEDs in normal situations remain Off. If LEDs devices are not all On, there is some security systems malfunction (photocells, safety edges). If "START" LEDs are on, there is a control device sending permanent signal.</p> <p><b>A) SECURITY SYSTEMS:</b></p> <p>1 • Close with a shunt all safety systems on the control board (check manual of the control board). If the automated system starts working normally check which device is problematic.<br/>2 • Remove one shunt at a time until you find the malfunction device.<br/>3 • Replace it for a functional device and check if the motor works correctly with all the other devices. If you find another one defective, follow the same steps until you find all the problems.</p> <p><b>B) START SYSTEMS:</b></p> <p>1 • Disconnect all wires connected to the START connector (LO and LE).<br/>2 • If the LED turned OFF, try reconnecting one device at a time until you find the defective device.</p> <p><b>NOTE:</b><br/>In case procedures described in sections A) and B) don't result, remove control board and send to our MOTORLINE technical services for diagnosis.</p> |
| • Motor doesn't make complete course. | • Unlock motor and move gate by hand to check for mechanical problems on the gate.   | • Encountered problems?                     | • Consult an experienced gates expert.  | 1 • Check all motion axis and associated motion systems related with the gate and automation (rails, pulleys, bolts, hinges, etc) to find out what is the problem.   |
|                                       |  | • The gate moves easily?                    | • Consult a qualified technician MOTORLINE.   | <p>1 • If the motors don't work, remove them from installation site and send to our MOTORLINE technical services for diagnosis.<br/>2 • If motor work well and move gate at full force during the entire course, the problem is on the control board. Make a new working time programming, giving enough time for opening and closing with appropriate force (consult control board manual).<br/>3 • If this doesn't work, remove control board and send it to MOTORLINE technical services.</p> <p><b>NOTE:</b><br/>Setting force of the control board should be enough to open and close the gate without stopping, but should stop and invert with a little effort from a person. In case of safety systems failure, the gate shall never cause physical damage to obstacles (vehicles, people, etc.).</p>  |





When the photocell test is active, the negative power supply to the photocells must be supplied by **connector 28 (B)**.