



MA4

INSTALLER AND USER'S MANUAL

EN

V3.1
REV. 09/2026

STEP 1 • Make the cable rise up at least 50mm above the fixation plate.

STEP 2 • After, descend the cable in a vertical position.

STEP 3 • To finalize, direct the cable horizontally to the motor.



Taking into account these indications, will ensure that the automatism is not damaged by humidity.


Technical Parameters

• Total cable length: **2,40m**

STEP 4 • Connect the cables to the control board, taking into account the position of the hot terminal and the cable ground.

ANTENNA HOT
POLE INPUT

ANTENNA MASS
INPUT



INSTALLATION

